Genie®



Operator's Manual

with Maintenance Information

First Edition
Fifth Printing
Part No. 38132

DPL™ Super Series™

Important

Read, understand and obey these safety rules and operating instructions before operating this machine. Only trained and authorized personnel shall be permitted to operate this machine. This manual should be considered a permanent part of your machine and should remain with the machine at all times. If you have any questions, call Genie Industries.

Contents

	Page
Safety Rules	1
Controls	7
Legend	8
Pre-operation Inspection	9
Maintenance	11
Function Tests	14
Workplace Inspection	17
Operating Instructions	18
Battery and Charger Instructions	20
Transport Instructions	21
Decals	22
Specifications	24

Contact us:

Internet: http://www.genieindustries.com
e-mail: techpub@genieind.com

Copyright © 1996 by Genie Industries

First Edition: Fifth Printing, April 2002

"Genie" and "DPL" are registered trademarks of Genie Industries in the USA and many other countries. "Super Series" is a trademark of Genie Industries.

This machine complies with ANSI/SIA 92.3-1990.

Printed on recycled paper

Printed in U.S.A.

Safety Rules



Danger

Failure to obey the instructions and safety rules in this manual will cause death or serious injury.

Do Not Operate Unless:

☑ You learn and practice the principles of safe machine operation contained in this operator's manual.

1 Avoid hazardous situations.

Know and understand the safety rules before going on to the next section.

2 Always perform a pre-operation inspection.

3 Always perform the function tests prior to use.

4 Inspect the workplace.

5 Only use the machine as it was intended.

☑ You read, understand and obey:

- manufacturer's instructions and safety rules—operator's manual and machine decals
- employer's safety rules and worksite regulations
- applicable governmental regulations

☑ The first time this machine is set up for use, a breather cap is installed. See Pre-operation Inspection section for breather cap instructions.

SAFETY RULES

Tip-over Hazards



Do not raise the platform unless the base is level, all four outriggers are properly set up and the leveling jacks firmly contact the ground.

Do not move the machine while the platform is raised.

Do not adjust or remove the outriggers while the platform is occupied or raised.

Do not place or attach overhanging loads to any part of this machine.



Do not raise the platform unless the machine is level. Do not set the machine up on a surface where it cannot be leveled using only the leveling jacks. Do not use chocks, blocks or shims of any kind to level the machine.


Do not place ladders or scaffolds in the platform or against any part of this machine.

Do not push off or pull toward any object outside the platform.

Do not use the machine to lift material or equipment. The machine is intended to lift personnel and tools to an aerial work site.

Do not use the machine on a moving or mobile surface or vehicle.

Do not operate the machine in strong or gusty winds. Do not increase the surface area of the platform or the load. Increasing the area exposed to the wind will decrease machine stability.





Do not exceed the rated platform load capacity.

Maximum capacity - DPL-25S		
ANSI	750 lbs	340 kg
CSA	600 lbs	272 kg
Maximum occupants - ANSI and CSA		2
CE	750 lbs	340 kg
Maximum occupants - CE Outdoor use Indoor use only		 1 2
Maximum capacity - DPL-30S		
ANSI	750 lbs	340 kg
CSA	600 lbs	272 kg
Maximum occupants - ANSI and CSA		2
CE	750 lbs	340 kg
Maximum occupants - CE Outdoor use Indoor use only		 1 2

Maximum capacity - DPL-35S		
ANSI	600 lbs	272 kg
CSA	500 lbs	227 kg
Maximum occupants - ANSI and CSA		2
CE	600 lbs	272 kg
Maximum occupants - CE Outdoor use Indoor use only		 1 2

Do not operate the machine near drop-offs, holes, bumps, debris, unstable or slippery surfaces or other possible hazardous conditions.

Do not alter or disable machine components that in any way affect safety and stability.

Do not replace items critical to stability with items of different weight or specification. Use only Genie authorized replacement parts.

When moving the machine with a forklift or other transport vehicle, the platform should be fully lowered, the guard rails should be down, the machine should be turned off and no personnel shall remain in the platform.

Fall Hazards



Do not sit, stand or climb on the platform guard rails. Maintain a firm footing on the platform floor at all times.


Do not enter or raise the platform unless the platform side guard rails are locked upright and the platform end guard rail and the platform entry gate are closed and latched.

Do not exit the platform while raised. If a power failure occurs, have ground personnel activate the manual lowering valve.

Keep the platform floor clear of debris.

SAFETY RULES

Electrocution Hazards



This machine is not electrically insulated and will not provide protection from contact with or proximity to electrical current.

Keep away from the machine if it contacts energized power lines or becomes electrically charged. Personnel on the ground or in the platform must not touch or operate the machine until the energized power lines are shut off.

Maintain safe distances from electrical power lines and apparatus in accordance with applicable governmental regulations and the following chart.

Voltage	Minimum Safe Approach Distance	
Phase to Phase	**Feet**	**Meters**
0 to 300V	Avoid Contact	
300V to 50KV	10	3.05
50KV to 200KV	15	4.60
200KV to 350KV	20	6.10
350KV to 500KV	25	7.62
500KV to 750KV	35	10.67
750KV to 1000KV	45	13.72

Allow for platform movement, electrical line sway or sag and movement due to strong or gusty winds.

Do not use the machine as a ground for welding.

Do not operate an AC powered machine or a DC battery charger unless using a 3-wire grounded extension cord connected to a grounded AC circuit. Do not alter or disable the 3-wire grounded plugs.

Collision Hazards

Check the work area for overhead obstructions or other possible hazards.

Be aware of crushing hazard when grasping the platform side guard rails.

Do not lower the platform unless the area below is clear of personnel and obstructions.

Be careful when transporting on an incline.

Stay clear of descending platform.

Component Damage Hazards

Do not operate the machine unless a breather cap has been installed in the hydraulic reservoir. See Pre-operation Inspection section for breather cap instructions.

Do not use the machine as an electrical ground for welding.

DC models: Do not operate the machine with a weak or overly discharged battery.

Improper Use Hazard

Do not leave the machine unattended unless the key is removed to secure from unauthorized use.

Damaged Machine Hazards

Do not use a damaged or malfunctioning machine.

Conduct a thorough pre-operation inspection of the machine and test all functions before each work shift. Immediately tag and remove from service a damaged or malfunctioning machine.

Be sure all maintenance has been performed as specified in this manual and the *Genie DPL Service Manual*.

Be sure all decals are in place and legible.

Be sure the operator's, safety and responsibilities manuals are complete, legible and in the storage container located in the platform.

Bodily Injury Hazard

Do not operate the machine with a hydraulic oil or air leak. An air leak or hydraulic leak can penetrate and/or burn skin.

Decal Legend

Genie product decals use symbols, color coding and signal words to identify the following:



Safety alert symbol—used to alert personnel to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

⚠DANGER Red—used to indicate the presence of an imminently hazardous situation which, if not avoided, will result in death or serious injury.

⚠WARNING Orange—used to indicate the presence of a potentially hazardous situation which, if not avoided, could result in death or serious injury.

⚠CAUTION Yellow with safety alert symbol—used to indicate the presence of a potentially hazardous situation which, if not avoided, may cause minor or moderate injury.

CAUTION Yellow without safety alert symbol—used to indicate the presence of a potentially hazardous situation which, if not avoided, may result in property damage.

NOTICE Green—used to indicate operation or maintenance information.

SAFETY RULES

Battery and Charger Safety - DC Models

Burn Hazards

Batteries contain acid. Always wear protective clothing and eyewear when working with batteries.





Avoid spilling or contacting battery acid. Neutralize battery acid spills with baking soda and water.

Explosion Hazards




Batteries emit explosive gas. Keep sparks, flames and lighted tobacco away from the battery.

Charge the battery in a well-ventilated area.

Do not disconnect the charger DC output wires from the battery when the charger is on.

The sliding door on the base cover must remain open during the entire charging cycle.

Electrocution Hazards



Connect the charger to a grounded AC circuit only.

Do not expose the battery or the charger to water or rain.


Before each use, inspect for damage. Replace damaged items before operating.

Lifting Hazard


The battery weighs 105 lbs / 48 kg. Use the appropriate number of people and proper lifting techniques when lifting the battery.

Controls


Ground Controls - AC & DC Models



Ground Controls - Air Models




Platform Controls



1 Red Emergency Stop button
2 Key switch
3 Outrigger interlock display lights (four)
4 Low battery indicator light for auxiliary lowering
5 DC models: Low battery indicator light
6 Power light
7 Auxiliary platform lowering button
8 Air pressure gauge
9 Control activate button
10 Up/Down switch

Legend



1 Platform end guard rail
2 Platform side guard rail
3 Manual storage container
4 Platform controls
5 AC outlet
6 Platform entry gate
7 Platform end gate latch
8 Platform
9 Interlock display
10 AC models: Circuit breaker
11 Platform entry ladder
12 AC models: Power supply for machine
DC models: AC power to platform
13 Platform entry ladder lock pin
14 Outrigger with leveling jack
15 Forklift pocket
16 Bubble level
17 Sequencing cable
18 Transport tie-down
19 Manual lowering lever
20 Battery charger plug-in
21 Base
22 Caster with swivel lock
23 Base cover
24 Mast
25 Steer handle
26 Platform guard rail locking handle
27 Guard rail lifting arm
28 Air line lubricator adjustment knob
29 Air supply for machine
30 Air line lubricator

Pre-operation Inspection

Do Not Operate Unless:

☑ You learn and practice the principles of safe machine operation contained in this operator's manual.

1 Avoid hazardous situations.

2 Always perform a pre-operation inspection.

Know and understand the pre-operation inspection before going on to the next section.

3 Always perform the function tests prior to use.


4 Inspect the workplace.

5 Only use the machine as it was intended.

Breather Cap - AC & DC Models

Component damage will occur if the machine is operated without a breather cap.

The first time this machine is set up for use, the pipe plug in the hydraulic reservoir, under the battery cover, must be removed and permanently replaced with a breather cap.



A breather cap is supplied and can be found in an envelope taped to the mast.

Fundamentals

It is the responsibility of the operator to perform a Pre-operation Inspection and routine maintenance.

The Pre-operation Inspection is a visual inspection performed by the operator prior to each work shift. The inspection is designed to discover if anything is apparently wrong with a machine before the operator performs the function tests.

The Pre-operation inspection also serves to determine if routine maintenance procedures are required. Only routine maintenance items specified in this manual may be performed by the operator.

Refer to the list on the next page and check each of the items and locations for modifications, damage or loose or missing parts.

A damaged or modified machine must never be used. If damage or any variation from factory delivered condition is discovered, the machine must be tagged and removed from service.

Repairs to the machine may only be made by a qualified service technician, according to the manufacturer's specifications. After repairs are completed, the operator must perform a pre-operation inspection again before going on to the function tests.

Scheduled maintenance inspections shall be performed by qualified service technicians, according to the manufacturer's specifications and the requirements listed in the responsibilities manual.

PRE-OPERATION INSPECTION

Pre-operation Inspection

- ❏ Be sure that the operator's, safety and responsibilities manuals are complete, legible and in the storage container located in the platform.
- ❏ Be sure that all decals are legible and in place. See Decals section.
- ❏ Check for battery fluid leaks and proper fluid level. Add distilled water if needed. See Maintenance section.
- ❏ AC & DC models: Check for hydraulic oil leaks and proper oil level. Add oil if needed. See Maintenance section.
- ❏ Air models: Check the oil level of the air line lubricator. Add oil as needed. See Maintenance section.
- ❏ Air models: Check the oil lubricator Canister drip rate. Adjust as needed. See Maintenance section.
- ❏ Air models: Check the air filter/regulator canister. Drain water as needed. See Maintenance section.

Check the following components or areas for damage and improperly installed, loose or missing parts:

- ❏ Electrical components and wiring
- ❏ Coil cord (if equipped)
- ❏ AC & DC models: Hydraulic power unit, hoses, fittings and cylinders
- ❏ Air models: Air power unit, air lines, hoses, fittings and cylinders
- ❏ Manual lowering lever
- ❏ Platform end guard rail, platform side guard rails and platform entry gate
- ❏ Guard rail lock handles
- ❏ Sequencing cables and pulleys
- ❏ Lifting chains and idler wheels
- ❏ Nuts, bolts and other fasteners
- ❏ Mast and mast braces
- ❏ Breather cap
- ❏ Outriggers, leveling jacks and footpads
- ❏ Guard rail lift arm
- ❏ Platform entry ladder

Check entire machine for:

- ❏ Dents or damage
- ❏ Corrosion or oxidation
- ❏ Crack in welds or structural components

- ❏ Inspect and clean battery terminals and all battery cable connections.
- ❏ Be sure that all structural and other critical components are present and all associated fasteners and pins are in place and properly tightened.

Maintenance



Observe and Obey:

☑ Only routine maintenance items specified in this manual shall be performed by the operator.

☑ Scheduled maintenance inspections shall be completed by qualified service technicians, according to the manufacturer's specifications and the requirements specified in the responsibilities manual.

Maintenance Symbols Legend

NOTICE The following symbols have been used in this manual to help communicate the intent of the instructions. When one or more of the symbols appear at the beginning of a maintenance procedure, it conveys the meaning below.

Indicates that tools will be required to perform this procedure.

Indicates that new parts will be required to perform this procedure.

Check the Battery - DC Models

Proper battery condition is essential to good machine performance and safe operation. Improper fluid levels or damaged cables and connections can result in engine component damage and hazardous conditions.

⚠WARNING Electrocution hazard. Contact with hot or live circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

⚠WARNING Bodily injury hazard. Batteries contain acid. Avoid spilling or contacting battery acid. Neutralize battery acid spills with baking soda and water.

NOTICE Perform this test after fully charging the batteries.

1 Put on protective clothing and eye wear.

2 Remove the battery vent caps.

3 Check the battery acid level. If needed, replenish with distilled water to the bottom of the battery fill tube. Do not overfill.

4 Install the vent caps.

MAINTENANCE

Check the Hydraulic Oil Level - AC and DC Models



Maintaining the hydraulic oil at the proper level is essential to machine operation. Improper hydraulic oil levels can damage hydraulic components. Daily checks allow the inspector to identify changes in oil level that might indicate the presence of hydraulic system problems.

1 Be sure the platform is fully lowered.

2 Check the sight gauge on the side of the hydraulic reservoir.

⊙ Result: The hydraulic oil level should be visible in the middle of the sight gauge. Do not overfill.

Hydraulic oil specifications	
Hydraulic oil type	Dexron equivalent

Check the Air Line Lubricator Oil Level - Air Models



Maintaining the proper oil level in the lubricator canister is essential to safe operation and good machine performance. Failure to keep the lubricator canister at the proper oil level could result in unsafe operating conditions and possible component damage.

1 Be sure the platform is fully lowered.

2 Inspect the lubricator canister for the proper oil level.

⊙ Result: The oil level must be within 1/2 inch / 12.7 mm from the top of the lubricator canister.

3 To add oil, remove the oil lubricator canister from the lubricator base and fill with oil. Install the canister back onto the lubricator base.

Oil Specifications	
Oil Type	10W automotive engine oil

Check the Oil Lubricator Canister Drip Rate - Air Models

Maintaining the proper oil drip rate into the lubricator canister is essential to safe operation and good machine performance. Failure to maintain the proper drip rate could result in machine component damage.

1 While raising the platform, visually inspect the oil lubricator sight gauge.

⊙ Result: There should be a maximum of 1 to 2 drops of oil visible in the sight gauge.

2 To adjust the drip rate, turn the oil flow control valve clockwise to decrease the flow or counterclockwise to increase the flow.

3 Repeat this procedure until the proper oil drip rate is achieved.

Check the Air Filter/Regulator Canister - Air Models

It is essential to drain the air filter/regulator canister of water to ensure good air motor performance and service life. A water-filled canister could cause the air motor to perform poorly and continued use could cause component damage.

1 Check the air filter/regulator canister for any water accumulation.

2 If water is visible, loosen the drain plug at the bottom of the canister and allow the water to drain out.

3 Tighten the drain plug.

Scheduled Maintenance

Maintenance performed quarterly, annually and every two years must be completed by a person trained and qualified to perform maintenance on this machine according to the procedures found in the service manual for this machine.

Machines that have been out of service for more than three months must receive the quarterly inspection before they are put back into service.

Function Tests



Do Not Operate Unless:

☑ You learn and practice the principles of safe machine operation contained in this operator's manual.

1 Avoid hazardous situations.

2 Always perform a pre-operation inspection.

3 Always perform the function tests prior to use.

Know and understand the function tests before going on to the next section.

4 Inspect the workplace.

5 Only use the machine as it was intended.

Fundamentals

The Function Tests are designed to discover any malfunctions before the machine is put into service. The operator must follow the step-by-step instructions to test all machine functions.

A malfunctioning machine must never be used. If malfunctions are discovered, the machine must be tagged and removed from service. Repairs to the machine may only be made by a qualified service technician, according to the manufacturers specifications.

After repairs are completed, the operator must perform a pre-operation inspection and function tests before putting the machine into service.

Function Tests

1 Position the machine directly below the desired work area.

2 Connect to the appropriate power source:
DC models: Connect the battery pack.
AC models: Connect to a grounded 15A AC power supply. Use a 12 gauge / 3.3 mm^2 3-wire grounded extension cord no longer than 50 feet / 13 m.
Air models: Connect the airline.

3 Insert the key and turn to the on position OR turn to platform control.


4 Pull out the red Emergency Stop button at the ground controls.

⊙ Result: AC & DC Models: The power light should come on.
Air models: The pressure gauge should read 80-110 psi / 5.5-7.8 bar.


5 Install each outrigger and adjust the leveling jacks to level the machine. Level the machine using only the outriggers. Do not use chocks, blocks or shims to level the machine.

6 Check the interlock display. Be sure that all four interlock display lights are on.

7 Use the bubble level and adjust the leveling jacks until the machine base is level.



8 Rotate the platform guard rail locking handle and rotate the platform side guard rail to the upright position. Be sure the side guard rail locks in place. Repeat for the other side.



9 Pull the ladder lock pins and rotate the ladder down. Be sure the ladder locks in place.


10 Climb the ladder to enter the platform. Close and latch the platform entry gate and the platform end guard rail.

Test Emergency Stop

11 Twist to release the red Emergency Stop button at the platform controls.

12 Push in the red Emergency Stop button at the ground controls to the off position.

13 Push in the control activate button and rotate the up/down switch in the direction of intended travel.



⊙ Result: The up/down function should not operate.

14 Push in the red Emergency Stop button at the platform controls to the off position.

15 Pull out the red Emergency Stop button at the ground controls to the on position.

16 Push in the control activate button and rotate the up/down switch in the direction of intended travel.

⊙ Result: The up/down function should not operate.

FUNCTION TESTS

Test Outrigger Interlock

17 Twist to release the red Emergency Stop button at the platform controls.

⊙ Result: The up/down function should operate.

18 Unscrew one leveling jack until the corresponding interlock display light turns off.

⊙ Result: The up/down function should not operate.

19 Return the leveling jack to the previous setting and check the bubble level.

20 Repeat the procedure for each outrigger.

Test Auxiliary Platform Lowering - AC & DC Models

21 Raise the platform slightly.

22 Disconnect the power source from the machine.

23 Turn the key switch to ground control (if equipped).

24 Push in the auxiliary platform lowering button at the ground controls.

⊙ Result: The platform should lower.

25 Connect the power source to the machine.

26 Turn the key switch to platform control (if equipped).

27 Raise the platform slightly.

28 Disconnect the power source from the machine.

29 Push in the control activate button and rotate the up/down switch in the down direction.

⊙ Result: The platform should lower.

30 Connect the power source to the machine.

Test Manual Lowering

31 Raise the platform slightly.

32 Activate the manual lowering lever.

⊙ Result: The platform should lower.

Workplace Inspection



Do Not Operate Unless:

☑ You learn and practice the principles of safe machine operation contained in this operator's manual.

1 Avoid hazardous situations.

2 Always perform a pre-operation inspection.

3 Always perform function tests prior to use.

4 Inspect the workplace.

Know and understand the workplace inspection before going on to the next section.

5 Only use the machine as it was intended.

Fundamentals

The Workplace Inspection helps the operator determine if the workplace is suitable for safe machine operation. It should be performed by the operator prior to moving the machine to the workplace.

It is the operator's responsibility to read and remember the workplace hazards, then watch for and avoid them while moving, setting up and operating the machine.

Workplace Inspection

Be aware of and avoid the following hazardous situations:

- drop-offs or holes
- bumps, floor obstructions or debris
- overhead obstructions and high voltage conductors
- hazardous locations
- inadequate surface support to withstand all load forces imposed by the machine
- wind and weather conditions
- the presence of unauthorized personnel
- other possible unsafe conditions

Operating Instructions

Do Not Operate Unless:

☑ You learn and practice the principles of safe machine operation contained in this operator's manual.

1 Avoid hazardous situations.

2 Always perform a pre-operation inspection.

3 Always perform function tests prior to use.

4 Inspect the workplace.

5 Only use the machine as it was intended.

Fundamentals

Using the machine for anything other than lifting personnel and material to an aerial work site is unsafe.

If more than one operator is expected to use a machine at different times in the same work shift, each operator is expected to follow all safety rules and instructions in the operator's manual. That means every new operator should perform a pre-operation inspection, function tests and a workplace inspection before using the machine.

Setup

1 Position the machine directly below the desired work area.

2 Connect to an appropriate power source:
DC models: Connect the battery pack.
AC models: Connect to a grounded 15A AC power supply. Use a 12 gauge / 3.3 mm² 3-wire grounded extension cord no longer than 50 feet / 13 m.
Air models: Connect the air line.


3 Insert the key and turn to the on position OR turn to platform control.

4 Pull out the red Emergency Stop button at the ground controls. Be sure the power light is on or the air pressure gauge reads 80-110 psi / 5.5-7.8 bar.

5 Install the outriggers and adjust the leveling jacks to level the machine. Check the bubble level to be sure the machine is level.

6 Check the interlock display. Be sure that all four interlock display lights are on.

7 Pull down on the platform guard rail locking handle and rotate the platform side guard rail to the upright position. Be sure the side guard rail locks in place. Repeat for the other side.



8 Pull the ladder lock pins and rotate the ladder down. Be sure the ladder locks in place.

9 Climb the ladder to enter the platform. Close and latch the platform entry gate and the platform end guard rail.

Emergency Stop

1 Push in the red Emergency Stop button at the platform controls or at the ground controls to stop the up function.

Platform Raise and Lower

1 Twist to release the red Emergency Stop button.

2 Push in the control activate button and rotate the up/down switch in the desired direction of travel.

Manual Lowering

1 Activate the manual lowering lever.

Auxiliary Platform Lowering - AC & DC Models

1 Turn the key switch to the on position OR turn to ground control. Pull out the red Emergency Stop button to the on position.

2 Activate the auxiliary platform lowering button at the ground controls.

After Each Use

1 Select a safe storage location—firm, level surface, weather protected, clear of obstruction and traffic.

2 Remove the key to secure from unauthorized use.

3 DC models: Recharge the battery.

OPERATING INSTRUCTIONS


Battery and Charger Instructions

Observe and Obey:

- ☑ Do not use an external charger or booster battery.
- ☑ Charge the battery in a well-ventilated area.
- ☑ Use the proper AC input voltage for charging as indicated on the charger.
- ☑ Use only Genie authorized battery and charger.

To Charge Battery:


1 Slide open the battery cover to access the charger and the battery. The cover must remain open for the entire charging cycle.



2 Remove the battery vent caps and check the battery acid level. If necessary, add only enough distilled water to cover the plates. Do not overfill prior to the charge cycle.

3 Install the battery vent caps.

4 Connect the battery charger to a grounded outlet of proper voltage and amperage as indicated on the battery charger.



5 Set the timer based on the amount of use:

Light Use (less than 15 lifting cycles): Set to 7 hours.

Heavy Use (greater than 15 lifting cycles): Set to the ON position.

6 The charger will automatically shut off at the end of the set period.

Note: If the ammeter drops to 3A or less within the first 15 minutes, the battery is fully charged.

7 Check the battery acid level when the charge cycle is complete. Replenish with distilled water to the bottom of the fill tube.

Dry Battery Filling And Charging Instructions

1 Remove the battery vent caps and permanently remove the plastic seal from the battery vent openings.

2 Fill each cell with battery acid (electrolyte) until the level is sufficient to cover the plates.

Do not fill to the maximum level until the battery charge cycle is complete. Overfilling can cause battery acid to overflow during charging. Neutralize battery acid spills with baking soda and water.

3 Install the battery vent caps.


4 Charge the battery for seven hours or until the charger ammeter reads 3A or less.

5 Check the battery acid level when the charge cycle is complete. Fill with distilled water to the bottom of the fill tube.

Transport Instructions

Observe and Obey:

- ☑ Common sense and planning must be applied to control the movement of the machine when lifting it with a crane or forklift.
- ☑ The transport vehicle must be parked on a level surface.
- ☑ The transport vehicle must be secured to prevent rolling while the machine is being loaded.
- ☑ Vehicle capacity, loading equipment and surfaces must be capable of supporting the machine weight. See Specifications section.
- ☑ The machine must be secured to the transport vehicle with chains or straps of ample load capacity.



1 transport tie-down points

Loading the Machine With a Forklift

1 Lower the platform.

2 Lower the platform side guard rails, the platform end guard rail and the platform entry gate. Secure the side guard rails with the tie-down strap.

3 Push in the red Emergency Stop buttons, turn the key switch to the off position and remove the key.

4 Inspect the entire machine for loose or unsecured items.

5 Use the forklift pockets located on the sides of the machine.

Winching the Machine onto a Flatbed Truck

1 Lower the platform.

2 Lower the platform side guard rails, the platform end guard rail and the platform entry gate. Secure the side guard rails with the tie-down strap.

3 Push in the red Emergency Stop buttons, turn the key switch to the off position and remove the key.

4 Inspect the entire machine for loose or unsecured items.

5 Connect the cable to the winching point (tie-down points) located on the base.

6 Carefully winch the machine onto the truck.

7 Secure the machine base and masts to the transport vehicle. Use chains or straps of ample load capacity.

Decals

Decal Inspection


Use the picture on the next page to verify that all decals are legible and in place.

Below is a numerical list with quantities and descriptions.

Part No.	Description	Quantity
27857	Caution - Component Damage	1
27865	Label - Bubble Level	2
27868	Danger - Tip-over, Relief	1
28157	Label - Dexron	1
28176	Notice - Missing Manuals	1
28236	Warning - Failure To Read	1
31076	Notice - 8A Max	1
37118	Warning - Bodily Injury Hazard	1
38142	Label - Circuit Breaker	1
40464	Interlock Display - AC and DC Models	1
40465	Notice - Manual Lowering Lever	1
40466	Danger - General Safety	2
40467	Notice - Operating Instructions, Ground	1
40468	Notice - Operating Instructions, Platform	1
40469	Danger - Tip-over/Fall Hazard	1
40514	Warning - Guard rail lock handle	2
40515	Notice - Max Capacity 600 lbs / 272 kg, ANSI, CSA	1
40516	Danger/Notice - Battery Safety & Charger Instructions	1

Part No.	Description	Quantity
41216	Notice - Max Capacity 750 lbs / 340 kg, ANSI, CSA	1
41263	Notice - Max Capacity 500 lbs / 227 kg, ANSI, CSA	1
43662	Interlock Display - Air Motor Models	1
44999	Label - Control Activate	1
46230	Notice - Manual Force	1
62050	Cosmetic - DPL-25S	2
62051	Cosmetic - DPL-30S	2
62052	Cosmetic - DPL-35S	2
62939	Cosmetic - Genie Logo	2
62940	Cosmetic - DPL Super Series Logo	2
65292	Notice - Max Capacity 500 lbs / 227 kg, CE	1
65293	Notice - Max Capacity 600 lbs / 272 kg, CE	1
65294	Notice - Max Capacity 750 lbs / 340 kg, CE	1
65295	Notice - 20 in / 51 cm Outriggers, CE	4
65296	Notice - 26 in / 66 cm Outriggers, CE	4
72893	Interlock Display - AC and DC Models	1

DECALS


28236
28176
41263 or
40515 or
41216 or
65292 or
65293 or
65294
40468
40466
44999
31076
46230
37118
62939
40514
62940
40469
40464
or 43662
or 72893
38142
Serial Plate
27868
28157
27857
65295
or 65296
65295
or 65296
40516
40465
40467
62050
or 62051
or 62052
27865
40466
65295
or 65296

Specifications

Model	DPL-25S	DPL-30S	DPL-35S
Height, maximum working	31 ft 4 in 9.5 m	36 ft 11 m	40 ft 9 in 12.4 m
Height, maximum platform	25 ft 4 in 7.7 m	30 ft 9.1 m	34 ft 9 in 10.6 m
Height, guard rails stowed	78 in 1.98 m	78 in 1.98 m	78 in 1.98 m
Length, outriggers stowed	81 3/4 in 2.07 m	81 3/4 in 2.07 m	81 3/4 in 2.07 m
Width, outriggers stowed	31 1/2 in 80 cm	31 1/2 in 80 cm	31 1/2 in 80 cm
Outrigger footprint (l x w)	84 x 60 in 2.1 x 1.5 m	89 x 73 in 2.3 x 1.9 m	89 x 73 in 2.3 x 1.9 m
Platform dimensions (l x w)	72 x 27 1/2 in 1.83 m x 69.9 cm	72 x 27 1/2 in 1.83 m x 69.9 cm	72 x 27 1/2 in 1.83 m x 69.9 cm
Power source			
AC	220V or 115V	220V or 115V	220V or 115V
DC	12V	12V	12V
Air power	100 psi / 6.9 bar @ 80 cfm / 2.26 m^3/min	100 psi / 6.9 bar @ 80 cfm / 2.26 m^3/min	100 psi / 6.9 bar @ 80 cfm / 2.26 m^3/min
Shipping weight (AC / DC)	1375 / 1450 lbs 624 / 658 kg	1475 / 1550 lbs 669 / 703 kg	1575 / 1650 lbs 714 / 748 kg
Maximum capacity			
ANSI	750 lbs / 340 kg	750 lbs / 340 kg	600 lbs / 272 kg
CE	750 lbs / 340 kg	750 lbs / 340 kg	600 lbs / 272 kg
CSA	600 lbs / 272 kg	600 lbs / 272 kg	500 lbs / 227 kg

Ambient operating temperature	-20°F to 135°F -29°C to 57°C
Airborne noise emissions Maximum sound level at normal operating workstations (A-weighted)	80 dB

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice or obligation.

Distributed By:

Genie North America
Phone 425.881.1800
Toll Free USA and Canada
800.536.1800
Fax 425.883.3475

Genie Australia Pty Ltd.
Phone +61 7 3375 1660
Fax +61 7 3375 1002

Genie China
Phone +86 21 53852570
Fax +86 21 53852569

Genie Malaysia
Phone +65 98 480 775
Fax +65 67 533 544

Genie Japan
Phone +81 3 3453 6082
Fax +81 3 3453 6083

Genie Korea
Phone +82 25 587 267
Fax +82 25 583 910

Genie Brasil
Phone +55 11 41 665 755
Fax +55 11 41 665 754

Genie Holland
Phone +31 183 581 102
Fax +31 183 581 566

Genie Scandinavia
Phone +46 31 3409612
Fax +46 31 3409613

Genie France
Phone +33 (0)2 37 26 09 99
Fax +33 (0)2 37 26 09 98

Genie Iberica
Phone +34 93 579 5042
Fax +34 93 579 5059

Genie Germany
Phone +49 (0)4202 88520
Fax +49 (0)4202 8852-20

Genie U.K.
Phone +44 (0)1476 584333
Fax +44 (0)1476 584334

Genie Mexico City
Phone +52 55 5666 5242
Fax +52 55 5666 3241