
TEREX Woodsman

730 BRUSH CHIPPER

Parts Manual



Customer _____

Dealer _____

S/N _____ Frame # _____

Date _____

TEREX Woodsman

1250 Commerce Drive, Farwell MI 48622

Phone: (800) 953-5532

Fax: (989) 588-4827




Flipper
Discharge Chute
Hand
Crank
Belt Shield
Tongue
Yoke
Safety Bar
Stabilizer
Leg
Battery
Box
Fuel Tank
Hydraulic
Tank
Tailgate


TABLE OF CONTENTS

Chipper Components	4-7
Chipper Drum	8-9
Feed Wheel and Yoke	10-11
Down Pressure System	12-13
Detent Assembly	14-15
Hydraulic Tank	16-17
Fuel Tank	16-17
Discharge Chute	18-19
Hand Crank	20-21
Winch	22-23
5200 lb Hub & Axle	24-25
6000 lb Hub & Axle	26-27
Twin Disc 111 Clutch	28-29
NACD 10” HE Clutch	30-33
NACD 11.5” HE Clutch	34-37
Auto Clutch HD 1300	38-41
Hydraulic System	32-43
Hydraulic System w/Winch	44-45
Electrical - Trailer System 12V	46-47
Electrical System	48-49
Electrical System w/ E Stop	50-51
Electrical System w/E Stop and Winch	52-53
Safety Decals	54-57
English - Spanish Decals	58-61


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22


ITEM	PART NO.	QTY	DESCRIPTION
1	40055418	1	Chute Assembly
2	41002100	1	Hand Crank Assembly
3	40015100	1	T Handle
4	41021730	1	Drum Cover
5	40039730	1	Yoke Cover
6	41002730	1	Yoke Complete
7	22004052	3	Mount - Lift Handle
8	40038730	1	Lift Handle
9	40013730	1	Safety Bar
10	26010138	2	Taillight
10a	26010143	2	Rubber Grommet
11	30263730	1	Infeed Curtain
12	40012730	1	Tailgate
13	30213730	2	Rubber Pad
14	41007730	1	Hydraulic Tank
15	41006730	1	Fuel Tank
16	40014730	1	Bolt On Fender
17	25501004	2	Rubber Latch
18	40024730	1	Bolt on Battery Box
19	30123730	1	Clutch Cover
20	40018730	1	Adjustable Tongue
21	40007730	1	Transition Weldment
22	40032418	1	Chute Swivel Base

AR - As Required NS - Not Shown


14
15
16
12
1
13
2
6
7
11
8
10
4
9
3
5


ITEM	PART NO.	QTY	DESCRIPTION
1	40055418	1	Discharge Weldment
2	41002100	1	Hand Crank Assembly
3	40021730	1	Belt Shield
4	26001060	1	Manual Holder
5	40018730	1	Adjustable Tongue
6	22015032	1	Hydraulic Block
7	40024730	1	Battery Box
8	40022730	1	Bolt on Fender
9	26126306	2	Tire
10	26102000	1	Axle
11	41002730	1	Yoke & Feed Wheel Assembly
12	40013730	1	Safety Bar
13	40012730	1	Infeed Tailgate
14	40038730	1	Control Arm Assembly
15	41015730	1	Detent Box Complete
16	22004052	3	Plastic Mount - Lift Handle

AR - As Required NS - Not Shown


9
6
7
8
5
3
1
4
2
10


ITEM	PART NO.	QTY	DESCRIPTION
-	41001730	1	Drum Complete
1	40002730	1	Drum Weldment
2	30019410	1	Drum Shaft
3	21004001	2	Bearings
4	20010039	2	Bushings
5	30080410	2	Drum Shim
6	50003008	2	Knife 6”
7	50003004	2	Knife 12”
8	24717001	18	Stud
9	24801208	18	Stover Flange Nut
10	30165410	2	Key Stock

AR - As Required NS - Not Shown


11
15
14
12
7
5
1
16
2
6
4
10
8
3
13

ITEM	PART NO.	QTY	DESCRIPTION
-	41002730	1	Complete Assembly
1	40004730	1	Pivot Arm
2	40005730	1	Feed Wheel Mount - Bearing Side
3	40006730	1	Feed Wheel Mount - Motor Side
4	40037730	1	Feed Wheel Weldment
5	21000067	1	Flange Bearing
6	24710305	4	Carriage Bolt
7	24801108	8	Stover Nut
8	22040115	1	Feed Wheel Motor
10	24410001	4	Carriage Bolt
11	40008730	1	Slot Cover
12	40009730	1	Slot Cover
13	24702442	8	Bolt
14	24650110	8	Washer Flat
15	24801110	8	Stover Nut
16	21004030	2	Split Bushing


AR - As Required NS - Not Shown


1
4
2
5
3
6

DOWN PRESSURE SPRING


ITEM	PART NO.	QTY	DESCRIPTION
-	41010730	1	Complete Assembly
1	40025730	1	Lug Weldment
2	40026730	1	Adjustor Plate
3	19500039	1	Spring
4	24801116	1	Stover Nut
5	40028730	1	Spring Sleeve
6	40027730	1	Bottom Lug Weldment


AR - As Required NS - Not Shown


3
17
16
1
18
20
2
15
10
14
6
5
11
8
7
9
13
12
4
19

ITEM	PART NO.	QTY	DESCRIPTION
-	41015730	1	Complete Assembly
1	40040730	1	Box Weldment
2	26053040	2	Switch
3	30256730	1	Box Cover
4	21015015	1	Roller Bearing
5	30166730	1	Linkage
6	30206730	1	Linkage
7	24413230	1	Eye Bolt
8	24650230	3	Washer Flat
9	24801107	2	Stover Nut
10	19500041	1	Detent Spring
11	24402209	1	Bolt
12	24650232	4	Washer
13	24702308	2	Bolt
14	24801108	2	Stover Nut
15	26053045	2	Switch Lever
16	24600206	4	Washer Lock
17	24402203	4	Bolt
18	30257730	1	Linkage
19	19500024	2	Spring
20	24650234	1	Washer Flat

AR - As Required NS - Not Shown


6
5
3
2
7
1
4


3
4
1
2


HYDRAULIC TANK

ITEM	PART NO.	QTY	DESCRIPTION
-	41007730	1	Complete Assembly
1	40020730	1	Tank Weldment
2	22003073	1	Tank Cap
3	22003004	1	Filter Housing w/Filter
3a	22003025	1	Drop in Filter
4	22000705	1	Magnetic Plug
5	24600206	2	Washer Lock
6	24402209	2	Bolt
7	22003049	1	Sight Gauge

FUEL TANK


ITEM	PART NO.	QTY	DESCRIPTION
-	41006730	1	Complete Assembly
1	40019730	1	Tank Weldment
2	22000093	1	Magnetic Drain Plug
3	22003055	1	Sight Gauge -21”
4	22003073	1	Tank Cap

AR - As Required NS - Not Shown


16
2
13
12
15
3
4
16
11
14
10
5
1
6
7
8
9
17
16
11
2a


ITEM	PART NO.	QTY	DESCRIPTION
-	41001418	1	Complete Assembly
1	40032418	1	Swivel Base
2	40032418	1	Chute
2a	25501004	2	Rubber Latch (NS)
3	24650110	8	Washer Flat
4	24702411	4	Bolt
5	2480110	4	Stover Nut
6	30182418	1	Chute Sprocket
7	30096418	4	Shim - 1/8”
8	30086418	4	Shim - 1/4”
9	24702312	8	Bolt 1/2” x 2”
10	24801108	8	Stover Nut
11	30067418	1	Bottom Door (Requires welding)
12	19500026	1	Spring
13	30119418	1	Retainer
14	24020052	1	Cotter Pin
15	30101418	1	Flipper (Requires welding)
16	30234418	2	Hinge
17	40032418	1	Complete Assembly (10/08)

AR - As Required NS - Not Shown


9
5
8
3
2
6
10
DRILL INDENT IN SHAFT IN TWO PLACES THAT LINE UP WITH SET SCREWS ON SPROCKET
1
4
7

ITEM	PART NO.	QTY	DESCRIPTION
-	41002100	1	Complete Assembly
1	40002100	1	Base Assembly
2	40024100	1	Sprocket Assembly
3	30262418	1	Bottom Shield
4	40025100	1	Adjustor Plate
5	24650230	8	Washer
6	24801107	6	Stover Nut
7	40015100	1	T - Handle
8	30263418	1	Top Shield
9	24402217	3	Bolt
10	24500206	1	Hex Nut


AR - As Required NS - Not Shown



9
7
10
15
16
14
29
28
11
3
17
6
8
26
1
13
12
25
19
27
18
24
4
5
20
21
2
22
23

ITEM	PART NO.	QTY	DESCRIPTION
-	41012130	1	Complete Assembly
1	40034130	1	Winch Housing
2	21000479	2	Pillow Block Bearing 2”
3	40020130	1	Bearing Mount
4	40004130	1	Winch Drum Weldment
5	40027130	1	Bearing Mount
6	40028130	1	Inner Shaft
7	22040001	1	Hydraulic Motor
8	30056130	1	Winch Cover
9	30092130	1	Handle
10	40022130	1	Torque Arm
11	30062130	1	Valve Mount
12	24600205	8	Lock Washer 5/16
13	24402153	4	Bolt 5/16-18 x 3/4” HHCS G5 ZP
14	24650106	10	Flat Washer 3/8
15	24402207	4	Bolt 3/8-16 x 1 1/4” HHCS
16	24402205	1	Bolt 3/8-16 x 1 HHCS G5 ZP
17	24801107	5	Stover Nut 3/8-16
18	24710305	8	Carriage Bolt 1/2-13 x 1 1/2”
19	24650108	12	Flat Washer 1/2”
20	24600208	8	Lock Washer 1/2”
21	24500208	8	Hex Nut 1/2-13 G5 ZP
22	24650110	8	Flat Washer 5/8”
23	24702411	4	Bolt 5/8-11 x 2” HHCS ZP
24	24801110	4	Stover Nut 5/8-11 GRD C
25	41002130	1	Fairlead Assembly
26	24702308	2	Bolt 1/2-13 x 1 1/2” HHCS G8 ZP
27	24801108	2	Stover Nut 1/2-13 GRD C
28	24402155	4	Bolt 5/16-18 x 1” HHCS G5 ZP
29	19500029	2	Extension spring

AR - As Required NS - Not Shown

5200 lb Axle



1
2
3
4
5
6
7
8
9
10
11
12
13
14
Exp5200



15
Forward
16
24
19
23
25
18
17
22
19
26
22
27
19
27
20
21

ITEM	PART NO.	QTY	DESCRIPTION
1	26103066	1	Grease Seal
2	26103067	1	Cone - Inner Bearing
3	26103068	1	Cup - Inner Bearing
4	26103069	1	DXQ Electric Brake Assembly - **Left**
4a	26103070	1	DXQ Electric Brake Assembly - **Right**
5	26103071	1	Hub and Drum
6	26123007	6	Studs
7	26102021	1	Cup - Outer Bearing
8	26102022	1	Cone - Outer Bearing
9	26103075	1	Spindle Nut
10	26102022	1	Grease Cup E-Z Lube
11	26104083	1	Rubber Plug for E-Z Lube
12	26103077	1	Spindle Nut Retainer
13	26103074	1	Spindle Washer
14	26123008	6	Nut
15	26103053	1	Backing Plate Assembly
16	26103055	1	LH Actuating Lever Arm
16a	26103056	1	RH Actuating Lever Arm
17	26103061	2	Wire Clip
18	26103062	2	Retractor Spring
19	26103060	1	Shoe and Lining Kit
20	26103054	1	Adjustor Assembly
21	26103064	1	Adjusting Screw Spring
22	26103058	1	Magnet Kit
23	26103052	1	Adjustor Slot Plug
24	26103078	1	Wire Grommet
25	26103079	1	Anchor Post Washer
26	26103081	5	Nut Washer
27	26103051	2	Shoe Hold Down Spring

AR - As Required NS - Not Shown


6000 lb Axle


1
2
3
4
5
6
7
8
9
10
11
12
13
14
Exp6000


15
Forward
16
24
19
23
17
22
25
18
19
26
22
27
19
27
20
21


ITEM	PART NO.	QTY	DESCRIPTION
1	26103066	1	Grease Seal
2	26103067	1	Cone - Inner Bearing
3	26103068	1	Cup - Inner Bearing
4	26103069	1	DXQ Electric Brake Assembly - **Left**
4a	26103070	1	DXQ Electric Brake Assembly - **Right**
5	26103071	1	Hub and Drum
6	26123007	8	Studs
7	26102021	1	Cup - Outer Bearing
8	26102022	1	Cone - Outer Bearing
9	26103075	1	Spindle Nut
10	26102020	1	Grease Cup E-Z Lube
11	26104083	1	Rubber Plug for E-Z Lube
12	26103077	1	Spindle Nut Retainer
13	26103074	1	Spindle Washer
14	26123008	8	Nut
15	26103053	1	Backing Plate Assembly
16	26103055	1	LH Actuating Lever Arm
16a	26103056	1	RH Actuating Lever Arm
17	26103061	2	Wire Clip
18	26103062	2	Retractor Spring
19	26103060	1	Shoe and Lining Kit
20	26103054	1	Adjustor Assembly
21	26103064	1	Adjusting Screw Spring
22	26103058	1	Magnet Kit
23	26103052	1	Adjustor Slot Plug
24	26103078	1	Wire Grommet
25	26103079	1	Anchor Post Washer
26	26103081	5	Nut Washer
27	26103051	2	Shoe Hold Down Spring

AR - As Required NS - Not Shown


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16


ITEM	PART NO.	QTY	DESCRIPTION
1	27000526	1	Key
2	27000507	1	Hub and Back Plate
3	27000506	1	Plate, Friction
4	27000537	1	Plate, Pressure
5	27000516	3	Lever
6	27000514	6	Washer
7	27000515	3	Pin, Clevis
8	27000513	3	Pin, Cotter
9	27000517	6	Pin, Clevis
10	27000519	6	Pin, Cotter
11	27000538	1	Ring, Adjusting
12	27000520	1	Sleeve, Sliding
13	27000518	6	Link
14	27000539	1	Collar, Assembly
15	27000528	1	Spring, Compression
16	27000529	1	Pin
NS	27000500	1	Clutch Pack
NS	27000509	1	Pilot Bearing
NS	27000522	1	Hub Nut
NS	27000523	1	Washer

AR - As Required NS - Not Shown


12
13
11
25
26
27
24
28
9
10
17
4
2
8
20
9
7
33
5
1
15
33
14
34
35
49
42
40
43
48
58
44
52
51
50
45
46
63
50
47
57
55
53
56
54
59
60

ITEM	PART NO.	QTY	DESCRIPTION
-	27001009	1	Complete Clutch
--	27001025	1	Clutch Pack
1	27001010	1	Bell Housing
2	27001011	1	Name Plate
4	27001012	2	Bolt
5	27001013	1	Grease Fitting
7	27001014	1	Grease Zerk
8	27001015	1	Drive Shaft
9	27001016	2	Main Bearings
10	27001017	1	Bearing Retainer
11	27001018	1	Adjusting Lock
12	27001019	1	Lock Bolt
13	27001020	1	Lock Washer
14	27001021	1	Cross Shaft
15	27001022	2	Woodruff Key
17	27001023	1	Yoke Sub Assy
20	27001024	1	Shifting Lever
24	27001027	1	Output Key
25	27001082	1	Pilot Bearing
26	27001028	1	Nut
27	27001029	1	Locking Washer
28	27001030	1	Clutch Key
33	27001042	2	Grease Fitting
34	27001031	1	Cover Plate
35	27001032	1	Machine Screw


AR - As Required NS - Not Shown


12
13
11
25
26
27
24
28
9
10
17
4
2
20
8
9
7
33
5
1
15
33
14
34
35
49
42
40
48
43
58
44
52
51
50
46
45
63
53
47
57
55
53
56
54
59
60

ITEM	PART NO.	QTY	DESCRIPTION
40	27001033	1	Drive Ring
41	27001025	1	Clutch Assembly (incl. - 42 - 58)
42	27001034	1	Clutch Body
43	27001026	1	Facing Plate
44	27001035	1	Pressure Ring
45	27001036	1	Adjusting Plate
NS	27001081	AR	Small Part Repair Kit (incl. 46 - 58)
46*	-	1	Lever Spring
47*	-	3	Lever
48*	-	3	Clevis Pin
49*	-	3	Retaining Ring
50*	-	1	Lock Bolt
51*	-	1	Lock Washer
52*	-	1	Adjustment Lock
53*	-	6	Link Pin
54*	-	3	Clevis Pin
55*	-	3	Retaining Pin
56*	-	3	Clevis Pin
57*	-	3	Retaining Ring
58*	-	3	Separator Spring
59	27001037	1	Release Sleeve
60	27001038	1	Release Bearing
61	27001039	1	Sleeve/Brng Assy (incl. - 59 and 60)
62	27001040	1	Press Plate Assy (incl. - 44,45, and 63)
63	27001041	1	Wear Ring

* Items available only as part of the above small part repair kit.


AR - As Required NS - Not Shown


12
13
11
25
10
5
9
17
26
27
28
6
24
32
4
2
7
20
8
9
33
15
1
14
33
43
36
34
42
37
52
38
40
46
45
44
39
57
47
41
51
49
47
50
48
53
54

ITEM	PART NO.	QTY	DESCRIPTION
-	27001051	1	Complete Clutch
-	27001050	1	Clutch Pack
1	27001043	1	Bell Housing
2	27001044	1	Name Plate
4	27001012	2	Bolt
5	27001014	1	Grease Fitting
6	27001045	1	Jam Nut
7	27001014	1	Grease Fitting
8	27001046	1	Drive Shaft
9	27001047	2	Main Bearings
10	27001048	1	Bearing Retainer
11	27001049	1	Adjusting Lock
12	27001019	1	Lock Bolt
13	27001020	1	Lock Washer
14	27001052	1	Cross Shaft
15	27001022	2	Woodruff Key
17	27001023	1	Yoke Sub Assembly
20	27001053	1	Shifting Lever
24	27001054	1	Output Key
25	27001082	1	Pilot Bearing
26	27001028	1	Nut
27	27001029	1	Locking Washer
28	27001055	1	Clutch Key
32	27001056	1	Grease Tube
33	27001057	2	Grease Fitting
NS	27001058	1	Headless Setscrew

* Items available only as part of the above small part repair kit.


AR - As Required NS - Not Shown


12
13
11
25
10
5
9
17
26
27
28
6
24
4
32
2
7
20
8
9
33
15
1
14
33
43
36
34
42
37
52
38
40
46
45
44
47
41
39
51
57
49
47
50
48
53
54

ITEM	PART NO.	QTY	DESCRIPTION
34	27001059	1	Drive Ring
35	27001050	1	Clutch Assembly (incl. 36 - 52)
36	27001061	1	Clutch Body
37	27001061	1	Facing Plate
38	27001062	1	Pressure Plate
39	27001036	1	Adjusting Ring
NS	27001081	AR	Small Part Repair Kit (incl. 40 - 52)
40*	-	1	Lever Spring
41*	-	3	Lever
42*	-	3	Clevis Pin
43*	-	3	Retaining Ring
44*	-	1	Lock Bolt
45*	-	1	Lock Washer
46*	-	1	Adjustment Lock
47*	-	6	Link
48*	-	3	Clevis Pin
49*	-	3	Retaining Ring
50*	-	3	Clevis Pin
51*	-	3	Retaining Ring
52*	-	3	Separator Spring
53	27001037	1	Release Sleeve
54	27001038	1	Release Bearing
55	27001039	1	Sleeve/Brng Assembly (incl. -53 and 54)
56	27001063	1	Press Plate Assembly (incl. - 38, 39 and 57)
57	27001041	1	Wear Ring


* Items available only as part of the above small part repair kit.

AR - As Required NS - Not Shown


1
9
11
10
5
5
8
7
6
4
3
2
1
12
21
19
20
13
15
18
14
17
16


ITEM	PART NO.	QTY	DESCRIPTION
-	27001502	1	Complete Assy. (inc. 1,2,3,4,5,8,10,& 11)
1	27001503	8	Bolt 5/16 x 1 ,Gr 5
2	27001504	1	Cover - Bearing Retainer
3	27001505	1	Key
4	27001506	1	Shaft
5	27001507	3	Bearing
6	27001508	2	Bolt 9/16-12 x 1 3/4, Gr 5
7	27001509	4	Lock Washer
8	27001510	1	Housing
10	27001511	1	Snap Ring
11	27001512	1	Housing
12	27001513	1	Pilot Bearing (Perkins, Cat, Cummins)
12a	27001514	1	Pilot Bearing (John Deere)
13	27001515	1	Disc
14	27001516	1	Pressure Plate
15	27001517	1	Throw Out Bearing
16	27001518	1	Housing
17	27001519	8	Bolt 3/8-24 x 1 Gr5 (Perkins, Cat, Cummins)
17a	27001520	8	Bolt 3/8-16 x 1 Gr5 (John Deere)
18	27001521	8	Lock Washer
19	27001522	10	Bolt M10-1.5x30mm
19a	27001523	2	Bolt M10-1.5x45mm (John Deere)
19b	27001524	2	Bolt M10-1.5x35mm (Perkins)
20	27001525	12	Lock Washer
21	27001526	1	Diesel Clutch Decal
NS	**27001500**	**AR**	**Complete Auto Clutch**

AR - As Required NS - Not Shown


6
17
14
13
7
10
14
5
14
11
9
6
2
24
4
8
17
14
11
1
15
12
16
18
17
21
3
23
22
19
20


ITEM	PART NO.	QTY	DESCRIPTION
-	NA	1	Complete Assembly
1	27001527	1	Fork
1a	27001528	1	Fork Retainer (NS)
2	27001529	1	Linkage Lever
3	27001530	1	Linkage Bracket
4	27001531	1	Linkage Rod
5	27001532	1	Linkage Rod
6	27001533	3	Rod End
7	27001534	1	Lever Shaft
8	27001535	1	Shaft Housing
9	27001536	1	Grease Zerk
10	27001537	1	Handle
11	27001538	2	Bushing
12	27001539	2	Collar
13	27001540	1	Rocker Ball
14	27001541	8	Nut
15	27001542	1	Pivot Ball
16	27001543	1	Bolt
17	27001544	4	Lock Washer
18	27001545	1	Flat Washer
19	27001546	1	Bolt
20	27001547	1	Lock Nut
21	27001548	1	Lock Nut
22	27001549	1	Boot
23	27001550	1	Alignment Tool
24	27001551	1	Adjustment Tool

AR - As Required NS - Not Shown


1
2
A
B
B
A
7
3
4
T
P
GA
T
P
9
6
8
6a
5


ITEM	PART NO.	QTY	DESCRIPTION
-	40014904	1	Complete Hydraulic Schematic
1	22040115	1	Hydraulic Motor
2	22051208	1	Hydraulic Cylinder
3	22003040	1	Suction Strainer
4	22031016	1	Gear Pump LH
4	22031017	1	Gear Pump RH
5	22003004	1	Filter Complete
5a	22003025	1	Filter Element
6	22015032	1	Base Block (NS)
6a	22002003	1	Adjustable Relief
7	22015040	1	Sub Plate Relief
8	22015036	1	Yoke Valve
9	22015037	1	Feed Valve

AR - As Required NS - Not Shown


10
1
2
7
4
3
5
9
6
8
6a
A
B
T
P
GA


ITEM	PART NO.	QTY	DESCRIPTION
-	40014904	1	Complete Hydraulic Schematic
1	22040115	1	Hydraulic Motor
2	22051208	1	Hydraulic Cylinder
3	22003040	1	Suction Strainer
4	22031016	1	Gear Pump LH
4	22031017	1	Gear Pump RH
5	22003004	1	Filter Complete
5a	22003025	1	Filter Element
6	22015033	1	Base Block (NS)
6a	22002003	1	Adjustable Relief
7	22015040	1	Sub Plate Relief
8	22015036	1	Yoke Valve
9	22015037	1	Feed Valve
10	22040001	1	Winch Motor

AR - As Required NS - Not Shown


1
2
3
4
4
5
8
7
7
6
6


ITEM	PART NO.	QTY	DESCRIPTION
-	30042906	1	Trailer Electric Schematic
1	26094990	1	Trailer Pig Tail 6 Pole
2	26010146	1	Trailer Receptacle 6 Pole
3	26010200	1	Break Away Safety Switch
4	26103058	2	Magnet Kit 5200# and 6000#
5	26095034	1	Trailer Electrical Harness
6	26010138	2	Taillight - Red
6a	26010136	2	Taillight - Clear
7	26010139	2	Marker Light
8	26010145	1	License Plate Light

AR - As Required NS - Not Shown


+12
+12
FUSE
SWITCH
RELAY
85
87
87a
86
30
12V
RED
BLACK
GREEN
PURPLE
GRAY
ORANGE
YELLOW
YELLOW/WHITE
BLACK
WHITE
BROWN
BLUE
TACH PICK UP
TACH
ELECTRICAL BOX UNDER ENGINE
-12
+12
YD
YU
RF
FF
VICKERS
DG4V-3-0C-M-U-G7-60
VICKERS
DG4V-3-0C-VM-U-G7-61
FEED
YOKE
NO
1
2
3
4
4a
5
6
7
7a
7b
8


ITEM	PART NO.	QTY	DESCRIPTION
-	30020906	1	Complete Assembly
1	26050004	1	Auto Feed Tach
2	26055200	2	Inline Fuse w/cap
3	26055030	1	Switch -2 pos detent
4	26053040	2	Switch
4a	26053045	2	Lever
5	26053054	2	Plug Cord
6	26010146	1	Junction Box
7	22015050	4	Hydraulic Plug (Hershman)
7a	22015036	1	Yoke Valve
7b	22015037	1	Feed Valve
8		4	DO3 Coil
NS	26095045	1	Trailer Harness

AR - As Required NS - Not Shown


EMERGENCY STOP
Switch config - ALL MACHINES W/COMPUTER POWER
ENGINE KILL
TACH
SWITCH +12v STARTER
CHIPPER DOOR SWITCH
FEED
YOKE
ELECTRICAL BOX UNDER ENGINE
VICKERS
DG4V-3-0C-M-U-G7-60
VICKERS
DG4V-3-8C-VM-U-G7-61
FUSE
SWITCH
RELAY
+12
BLACK
RED
GREEN
PURPLE
GRAY
ORANGE
YELLOW
YELLOW/WHITE
BLUE
WHITE
BROWN
NC
NO
1
2
3
4
4a
5
6
7
7a
7b
8
9
10
11
12
13

ITEM	PART NO.	QTY	DESCRIPTION
-	30020906	1	Complete Assembly
1	26050004	1	Auto Feed Tach
2	26055200	2	Inline Fuse w/cap
3	26055030	1	Switch -2 pos detent
4	26053040	2	Switch
4a	26053045	2	Lever
5	26053054	2	Plug Cord
6	26010146	1	Junction Box
7	22015050	4	Hydraulic Plug (Hershman)
7a	22015036	1	Yoke Valve
7b	22015037	1	Feed Valve
8		4	DO3 Coil
9	26055017	2	E-Stop Button
10	26053016	2	E-Stop Box
11	26055121	2	Mounting Latch
11a	26055117	2	Contact Normally Closed
12	26010146	1	Safety Receptacle
13	40112901	1	Safety Plug
NS	26095045	1	Trailer Harness

AR - As Required NS - Not Shown


ALL WIRES JUNCTION INSIDE 6-POLE BOX
ELECTRICAL BOX
EMERGENCY STOP
Switch config - ALL MACHINES W/COMPUTER POWER
ENGINE KILL
TACH
SWITCH +12v STARTER
CHIPPER DOOR SWITCH
FEED
YOKE
WINCH
SELECTOR Winch/Feed
CABLE In/out
+12
FUSE
SWITCH
RELAY
BLACK
WHITE
RED
GREEN
BLUE
YELLOW
ORANGE
GRAY
PURPLE
BROWN
YELLOW/WHITE
YELLOW/BLACK
WHITE/BLACK/BLUE
1
2
3
4
4a
5
6
7
7a
7b
7c
8
9
10
11
12
13

ELECTRICAL with E-STOP and WINCH

ITEM	PART NO.	QTY	DESCRIPTION
-	30020906	1	Complete Assembly
1	26050004	1	Auto Feed Tach
2	26055200	2	Inline Fuse w/cap
3	26055030	1	Switch -2 pos detent
4	26053040	2	Switch
4a	26053045	2	Lever
5	26053054	2	Plug Cord
6	26010146	1	Junction Box
7	22015050	4	Hydraulic Plug (Hershman)
7a	22015036	1	Yoke Valve
7b	22015037	1	Feed Valve
7c	22015037	1	Winch Valve
8		4	DO3 Coil
9	26055017	2	E-Stop Button
10	26053016	2	E-Stop Box
11	26055121	2	Mounting Latch
11a	26055117	2	Contact Normally Closed
12	26010146	1	Safety Receptacle
13	40112901	1	Safety Plug
NS	26095045	1	Trailer Harness

AR - As Required NS - Not Shown

DANGER

FLYING DEBRIS

DANGER


USE LOCK OUT PROCEDURES WHEN CHANGING KNIVES.

DANGER

KEEP ACCESS DOOR CLOSED DURING OPERATION
SHUT MACHINE DOWN AND REMOVE KEY. WAIT FOR DRUM TO COME TO A COMPLETE STOP BEFORE OPENING.

WARNING

MOVING PARTS BEHIND GUARD



WARNING

FLAMMABLE FLUID
DIESEL FUEL ONLY

- Do not attempt to fill this tank with engine running!
- Do not fill fuel tank completely full.
- Allow two inches for fuel expansion.

WARNING

DO NOT GO NEAR LEAKS

- High pressure oil easily punctures skin causing serious injury, gangrene, or death.
- If injured, seek emergency medical help. Immediate surgery is required to remove oil.
- Do not use finger or skin to check for leaks.
- Lower load or relieve hydraulic pressure before loosening fittings.

CAUTION


MOVING PARTS

EXTREME DANGER

DO NOT REACH INTO THIS AREA WITH HANDS OR FEET.

ITEM	PART NO.	QTY	DESCRIPTION
-	29002000	1	Safety Decal Kit Complete
1	29002005	2	DANGER - Flying Debris
2	29002004	1	DANGER - Use Lock Out Procedures
3	29002008	1	DANGER - Keep Access Door Closed
4	29002003	2	WARNING - Moving Parts Behind Guard
5	29002007	2	EXTREME DANGER - Do Not Reach Into
6	29002027	2	CAUTION - Moving Parts
7	29002023	1	WARNING - Do Not Go Near Leaks
8	29002015	1	WARNING - Flammable Fluid
9	29002044	1	Woodsman Trees (black)
9a	29002043	1	Woodsman Trees (white)
10	29002076	1	Hydraulic Oil Only
11	29002084	2	730 decal (black)
11a	29002085	2	730 decal (white)
12	29002098	2	Woodsman decal (black)
12a	29002099	2	Woodsman decal (white)
13	29002019	1	Keep Radiator Clean
14	29002015	2	Feed Wheel Lift Cylinder
15	29002010	1	Safety Bar - Push to Reverse
NS	29002031	2	DOT Reflective Tape

AR - As Required NS - Not Shown



SAFETY BAR
Push To Reverse Chipper Feed Wheels
1

WARNING
MOVING PARTS BEHIND GUARD
2

DANGER
FLYING DEBRIS
3

4

5

WARNING
DO NOT OPERATE MACHINE WITHOUT GUARDS SECURELY IN PLACE.
6

WARNING
Do Not Operate This Machine Unless You Have Completely Read The Operator's Manual & Have Been Instructed In The Safe Operation Of This Machine.
7

WARNING
IT IS THE OWNERS RESPONSIBILITY TO REPLACE ANY DAMAGED OR MISSING DECALS ON THIS UNIT.
8

17

17

IMPORTANT
DO NOT ENGAGE CLUTCH AT SPEEDS ABOVE ENGINE IDLE
9

10

11

12

13

14

15

16

ATTENTION
SERVICE REQUIRED
Clutch Requires Manual Adjustments for Proper Operation.
Frequent Adjustments Are Necessary During Break In Period.
See Clutch Manual for Proper Settings.

CAUTION
MOVING PARTS


DANGER
THINK ABOUT WHAT YOU'RE DOING
There is absolutely no reason to reach into the infeed chute. If the feedwheel becomes tangled with small debris, shut down machine to untangle. Follow all operator instructions for this process. If you have short pieces or loose material, toss them into the infeed chute while longer material is feeding or don't feed the short pieces at all.

REMEMBER
1. Never operate this machine before reading the operators manual and understanding all operation, safety, and maintenance procedures!
2. Never operate this machine alone. At least two people at all times is recommended.
3. Never operate this machine when wearing loose clothing, scarves, gauntlet style gloves, or gloves with large cuffs or holes.

EXTREME DANGER
DO NOT REACH INTO THIS AREA WITH HANDS OR FEET.

ITEM	PART NO.	QTY	DESCRIPTION
-	29002000	1	Safety Decal Kit Complete
1	29002010	1	Safety Bar - Push to Reverse
2	29002003	2	WARNING - Moving Parts Behind Guard
3	29002008	2	DANGER - Flying Debris
4	29002098	2	Woodsman Decal (black)
4a	29002099	2	Woodsman Decal (white)
5	29002084	2	730 Decal (black)
5a	29002085	2	730 Decal (white)
6	29002016	1	WARNING - Do Not Operate Machine
7	29002017	1	WARNING - Do Not Operate This
8	29002011	1	WARNING - It is the owners
9	29002018	1	IMPORTANT - Do Not Engage Clutch
10	29002044	1	Woodsman Trees (black)
10a	29002043	1	Woodsman Trees (white)
11	29002024	1	ATTENTION - Service Required
12	26001060	1	Manual Holder
13	29002009	1	DANGER - Think About
14	29002027	2	CAUTION - Moving Parts
15	29002020	1	Feed Wheel Lift Cylinder
16	29002007	2	EXTREME DANGER - Do Not Reach
17	29002110	1	Auto Feed - On / Off
NS	29002031	2	DOT Reflective Tape

AR - As Required NS - Not Shown


DANGER
PELIGRO
FLYING DEBRIS
ESCOMBROS EN VUELO
DANGER
PELIGRO
USE LOCK OUT PROCEDURES WHEN CHANGING KNIVES.
USE LOS PROCEDIMIENTOS DE SEGURO QUE IMPIDEN EL MOVIMIENTO MIENTRAS CAMBIANDO LOS CUCHILLOS.
DANGER
PELIGRO
KEEP ACCESS DOOR CLOSED DURING OPERATION.
SHUT MACHINE DOWN AND WAIT FOR DRUM TO COME TO A COMPLETE STOP BEFORE OPENING.
Mantenga La Puerta de acceso Cerrada durante. La operacion
Y espere que el tambor llegue a una parada. Completamente ante de abrir La Puerta.
DANGER
PELIGRO
MOVING PARTS BEHIND GUARD
PARTES EN MOVIMIENTO DETRAS DEL PANEL DE SEGURIDAD.
Woodsman 730
Woodsman
CAUTION MOVING PARTS
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15


WARNING
ADVERTENCIA
FLAMMABLE FLUID DIESEL FUEL ONLY
LIQUIDO FLAMABLE SOLAINENTE DIESEL


WARNING
ADVERTENCIA
DO NOT GO NEAR LEAKS
NO VAYA CERCA DE LOS ESCAPES



CAUTION
MOVING PARTS


EXTREME DANGER
PELIGRO EXTREMADAMENTA
DO NOT REACH INTO THIS AREA WITH HANDS OR FEET.
NO SE EXTENDER EN ESTE AREA CON SUS MANOS NI PIES.

ENGLISH-SPANISH SAFETY DECALS

ITEM	PART NO.	QTY	DESCRIPTION
-	29002045	1	English-Spanish Safety Decal Kit Complete
1	29002034	2	DANGER - Flying Debris
2	29002033	1	DANGER - Use Lock Out Procedures
3	29002029	1	DANGER - Keep Access Door Closed
4	29002032	2	DANGER - Moving Parts Behind Guard
5	29002036	2	EXTREME DANGER - Do Not Reach Into
6	29002027	2	CAUTION - Moving Parts
7	29002028	1	WARNING - Do Not Go Near Leaks
8	29002038	1	WARNING - Flammable Fluid
9	29002044	1	Woodsman Trees (black)
9a	29002043	1	Woodsman Trees (white)
10	29002040	1	Hydraulic Oil Only
11	29002084	2	730 decal (black)
11a	29002085	2	730 decal (white)
12	29002098	2	Woodsman decal (black)
12a	29002099	2	Woodsman decal (white)
13	29002030	1	Keep Radiator Clean
14	29002025	2	Feed Wheel Lift Cylinder LH
15	29002042	1	Safety Bar - Push to Reverse
NS	29002031	2	DOT Reflective Tape

AR - As Required NS - Not Shown



DANGER | PELIGRO
MOVING PARTS BEHIND GUARD | PARTES EN MOVIMIENTO DETRAS DEL PANEL DE SEGURIDAD.

1

SAFETY BAR | BARRA DE SEGURIDAD
Push To Reverse Chipper Feed Wheels. | Empute para invertir las ruedas del cincelador tambien la rueda de alimentacion.

2

DANGER | PELIGRO
FLYING DEBRIS | ESCOMBROS EN VUELO

3

4

5

WARNING | ADVERTENCIA
DO NOT OPERATE MACHINE WITHOUT GUARDS SECURELY IN PLACE. | NO USE ESTE MAQUINA SIN TENER LOS PANELES DE SEGURIDAD SERGURAMENTE ASEGUARADOS.

6

WARNING | ADVERTENCIA
Do Not Operate This Machine Unless You Have Completely Read The Operator's Manual & Have Been Instructed In The Safe Operation Of This Machine. | No funcione esta maquina a menos que usted haya leido totalmente. El manual de operacion y las instrucciones, de la operacion de seguridad de esta maquina.

7

WARNING | ADVERTENCIA
IT IS THE OWNERS RESPONSIBILITY TO REPLACE ANY DAMAGED OR MISSING DECALS ON THIS UNIT. | ES LA RESPINSABILIDAD DEL DUENO DE REEMPLAYAR CUALQUIER ETIQUETA AVERIADA O PERDIDA EN ESTE MAQUINA.

8

17

17

IMPORTANT | IMPORTANTE
DO NOT ENGAGE CLUTCH AT SPEEDS ABOVE ENGINE IDLE | NO ENGAGE EL EMBRAGUE A LAS VELOCIDADES SOBRE MARCHA LENTA DEL MOTOR NUNCA ENGAGE EL EMBRAGUE A ALTA VELOCIDAD

9

10

11

12

13

14

15

16

ATTENTION | CUIDADO
SERVICE REQUIRED | SE REQUIERE SERVICIO

Nuevas bandas ajustables. Si no se encuentran ajustadas se deslizaran y se cristalizan. Esto no solo arruina la polea las bandas tambien arruina. Ajustarlas despues de dos horas de operacion y dos veces al dia hasta que las bandas esten firmamente ajustadas. La quemadura de las bandas no es cubierta por la garantia.

CAUTION
MOVING PARTS

DANGER | PELIGRO

THINK ABOUT WHAT YOU'RE DOING

There is absolutely no reason to reach into the infeed chute. If the feedwheel becomes tangled with small debris, shut down machine to untangle. Follow all operator instructions for this process. If you have short pieces or loose material, toss them into the infeed chute while longer material is feeding or don't feed the short pieces at all.

REMEMBER

1. Never operate this machine before reading the operators manual and understanding all operation, safety, and maintenance procedures!
2. Never operate this machine alone. At least two people at all times is recommended.
3. Never operate this machine when wearing loose clothing, scarves, gauntlet style gloves, or gloves with large cuffs or holes.

PIENSE EN LO QUE VA A HACER

No hay absolutamente razon para alcanzar en el canal. Si la rueda de alimentacion se enreda, con pedazos cortos o materiales sueltos. Tiene que apagar la maquina para desenredar siga todas las intrucciones del operador. Para este proceso, si usted tiene materiales cortos o materiales sueltos entre los materiales con los materiales [illegible] pero sies posible no entree los [illegible], cortos o los sueltos.

RECUERDE

1. Nunca funcione esta maquina antes de leer los manuales de operacion. Y de entender toda forma de seguridad y el mantenimiento de esta maquina!
2. Nunca funcione esta maquina solamente por lo menos se recomienda dos personas siempre.
3. Nunca funcione esta maquina con ropa floja y bufandas, guantes con agujeros y guantes de estilo gauntelete.

EXTREME DANGER | PELIGRO EXTREMADAMENTA
DO NOT REACH INTO THIS AREA WITH HANDS OR FEET. | NO SE EXTENDER EN ESTE AREA CON SUS MANOS NI PIES.



TEREX

ENGLISH-SPANISH SAFETY DECALS

ITEM	PART NO.	QTY	DESCRIPTION
-	29002045	1	English - Spanish Decal Kit Complete
1	29002042	1	Safety Bar - Push to Reverse
2	29002042	2	DANGER - Moving Parts Behind Guard
3	29002008	2	DANGER - Flying Debris
4	29002098	2	Woodsman Decal (black)
4a	29002099	2	Woodsman Decal (white)
5	29002084	2	730 Decal (black)
5a	29002085	2	730 Decal (white)
6	29002039	1	WARNING - Do Not Operate Machine
7	29002221	1	WARNING - Do Not Operate This
8	29002037	1	WARNING - It is the owners
9	29002222	1	IMPORTANT - Do Not Engage Clutch
10	29002044	1	Woodsman Trees (black)
10a	29002043	1	Woodsman Trees (white)
11	29002041	1	ATTENTION - Service Required
12	26001060	1	Manual Holder
13	29002220	1	DANGER - Think About
14	29002027	2	CAUTION - Moving Parts
15	29002026	1	Feed Wheel Lift Cylinder RH
16	29002036	2	EXTREME DANGER - Do Not Reach Into
17	29002110	1	Auto Feed - On / Off
NS	29002031	2	DOT Reflective Tape

AR - As Required NS - Not Shown